

UtiliMax Black

Water Activated & Fast Setting Asphalt Repair Material

TOOLS REQUIRED



Gloves



Tamp



Steel Rake



Watering Can

PRODUCT DESCRIPTION AND USE

QPR[®] UtiliMax Black is a dense graded and water activated material suitable for use on roads, driveways, and walkways as well as various utility operations where the repair of asphalt or blacktop is required. The product contains new modifier technology which provides superior placement and produces a virtually permanent repair in a short period of time, even in cold, damp conditions. Product will be fully cured in 24 hours. QPR UtiliMax Black is designed for small potholes, depressions, aprons, edging, berms and water control.

INSTALLATION PREPARATORY WORK

Square cut the vertical sides of the hole to provide for proper confinement of the patch. Remove all loose material. Sweep the area thoroughly.

APPLICATION

It is recommended that you wear impervious gloves such as nitrile when working with any asphalt material. Follow these procedures when applying QPR UtiliMax Black:

- The application should not be less than 1 in (25 mm) thick after final compaction. Fill the hole with QPR UtiliMax Black to a height of .5 in (13 mm) crowning above the surrounding area. Material over 2 in (50 mm) must be applied in 2 in (50 mm) lifts which must be adequately compacted before additional material is added.
- Pour water evenly across the entire repair. Approximately 1 pt (0.5 L) of water per square foot of area. Repeat for each layer.
- Compact to a level surface with a Mechanical or hand tamper. Apply additional water to the surface of the compacted area; enough that there is standing water on the surface.

PRECAUTIONS

- Apply QPR UtiliMax Black at a depth of 1 in - 4 in (25 - 100 mm). Apply in 2 in (50 mm) lifts so that adequate compaction of each layer can be accomplished before more material is added. The product is not designed for curbs or other unconfined areas or designed to replace the use Hot Mix Asphalt for large areas such as entire driveways or parking lots.
- Avoid getting QPR UtiliMax Black on hands or clothing
- Avoid dry turning tires on patched area until the material has hardened sufficiently (certain weather conditions may extend this period). Typical times can range from 1 to 5 hr.
- Follow asphalt sealer manufacturer's directions regarding application of sealers.
- Do not use for resurfacing paved areas

WARRANTY

The QPR[®] warrants this product to be of merchantable quality when used or applied in accordance with the instructions herein. The product is not warranted as suitable for any purpose or use other than the general purpose for which it is intended. Liability under this warranty is limited to the replacement of its product (as purchased) if found to be defective, or at the shipping companies' option, to refund the purchase price. In the event of a claim under this warranty, notice must be given to The QPR[®] in writing at:

The QUIKRETE[®] Companies, LLC
One Securities Centre
3490 Piedmont Rd., NE, Suite 1300, Atlanta, GA 30305

This warranty is issued and accepted in lieu of all other express warranties and expressly excludes liability for consequential damages.